



Fixing Instructions

Important Note

- For retrospective installations. Please ensure that the security fixings (currently locating the Keypad into position) are removed before applying the sealing gasket.
- ii) For new installations. Where the Privacy Shroud is to be used in conjunction with the wall mounted keypad and rear case, follow the installation instructions supplied with the keypad or rear case, however, do not fit the security screws until the Privacy Shroud is in position.
- Secure the self adhesive sealing gasket (A) to the front surface of the STORM Keypad. Please take care to ensure that the 'Knock Out' for the LED is removed, where appropriate.
- Locate the Privacy Shroud to the front surface of the Keypad and secure using the four secuity fixings (B).
 Important: please ensure that the nylon sealing washer is located beneath the head of the security screw (B). A security bit is provided for tightening these screws.

TECHNICAL DATA

Material: Extruded Aluminium

Surface Finish: Epoxy Powder Coat

(Satin Black)

Security Screws: A2 Stainless Steel Torx

Centre Pin

No 8 Self Tapping

Sealing Gasket: Self Adhesive Polymer

CD08. Issue 1

Keymat Technology Ltd